



Classic Car

Custom Seat Belts

Buy Auto Products

Panel Workshop

Classic Car Repairs

Import Cars

Restorations

Online

Contact Us

+61 7 3205 3205

info@gasolinealley.com.au

sales@gasolinealley.com.au

15 Strathwyn Street

Brendale, Queensland 4500.

Latest Headlines

- Sunday 2nd June 2013 OPEN DAY 9am
- 2012 OPEN DAY PHOTOS
- OPEN DAY 22 APRIL 2012
- OPEN DAY SUNDAY 10TH APRIL 2011
- Car Imports

Website Updates

Sunday 2nd June 2013 OPEN DAY 9am 10 years ago



DSC3170.JPG 11 years ago

1972 Ford Falcon 500 Utility 11 years ago

Home » FAQ

FAQ

When should I change the engine oil in my classic car?

Its always good practice to change engine oil and filter at least every three months regardless of r travelled. An engine that sits for long periods and then idles around town is prone to damage from impurities and acids formed in the oil pan. The engine never gets a chance to heat balance hence boils off the nasties.

My classic car has started to run hotter than normal. The temp gauge reads higher than it normally does and gets worse on the highway.

A couple of things may be happening. A quick diagnostic test is to check top hose and bottom hose temps. If the top hose feels hotter than the bottom radiator hose the radiator is probably starting to blocked internally with scale. Temp difference between top and bottom hoses is typically about 2C. This feels about the same or slightly cooler. A definite temp difference or a cold lower hose near coolant circulation. After checking water pump, thermostat, belts, fan operation and coolant level, radiator out and have it cleaned out by a radiator shop. Make sure they pull the tanks off and physically clean out the cores. Prior to refitting, flush out engine block replace thermostat. Early V8'S should 160F/71degC thermostat fitted (in hotter climate). Dose up with a good ethylene glycol corrosion inhibitor. Also try to run a radiator sock in the top hose to catch any scale. As these old girls become week and are used infrequently you may need to pull the radiator every twelve months or so to keep scale minimum.

PS. always check a new thermostat prior to installation by cooking it up in boiling water and check opening temp. They normally crack open right on the temp stated. It takes about another 10deg C to open.



- 12 years ago



- 12 years ago

